



Congratulations on owning a **Skaha II** folding knife! The Skaha is a modern folding knife that opens one-handed with the aid of a flipper tab. The Skaha is a light yet sturdy knife ideally suited to everyday carry.

Quick Specs

Blade Material: CPM MagnaCut stainless steel

Handle Material: G10 laminate or solid carbon fiber

Blade hardness: 61-63 HRC

Cutting edge angle(inclusive): 30°

Usage

Opening: Hold the knife by the back and pull firmly on the flipper tab with your index finger. This technique will deploy the knife rapidly and lock it open.

Closing: Push the lock-bar sideways into the handle recess with your thumb to unlock the blade and with the same hand guide the blade closed.

Carrying: The knife is designed for tip-up carry via the pocket clip. DO NOT remove the pocket clip screw as it also holds the lock bar in place.

Care

Sharpening: Our website offers helpful guidance to choosing and using sharpening tools. Avoid pull-through carbide sharpeners.

Cleaning: If your Skaha feels gritty or stiff, it probably needs a thorough washing and some lubricant. Please refer to our online FAQ on Skaha maintenance. **Don't remove the lockbar from the scale (handle) during disassembly. It's easy to damage during removal and difficult to install properly. Damage from doing so is not covered by warranty.**

Cautions:

- Periodically check for side to side blade play which indicates loosening pivot screws, that you'll want to tighten (Torx T10) before they get lost. The stand-off screws also need to be checked (Torx T8)
- The stainless steel in this knife can discolour under certain conditions (e.g. around salt water, acids). As soon as possible after such exposure, clean as described above.

For further information visit our website: **northarmknives.com**